


STEUERN DES MODELLS

- Stellen Sie das Modell so ab, dass die Räder frei in der Luft hängen.
- Drehen Sie das Steuerrad bis zum Anschlag nach rechts und links. Die Räder sollen dem Lenkausschlag folgen.
- Zum Regeln der Fahrgeschwindigkeit betätigen Sie den Gas/Bremshebel
  - nach hinten (Vorwärtsfahrt, Gas geben) bzw.
  - nach vorne (Bremsen, Rückwärtsfahrt)






A. GASHEBEL



B. LENKRAD




AUFLADEN DES FAHRAKKUS

Ladehinweise: Achtung !!

Wichtige Informationen über ihren wiederaufladbaren 7,2V NiMH Fahrakku:

1. Die Ladezeit für diesen 7.2V NiMH Fahrakku beträgt max. 3 Stunden, eine Überladung schädigt diesen und verkürzt die Lebensdauer.
2. Das Ladegerät und den Akku während des Ladevorganges nie unbeaufsichtigt lassen.
3. Wenn die Geschwindigkeit/Leistung Ihres RC-Modells nachlässt oder gar stehenbleibt, bitte sofort den Betrieb einstellen und den Akku wieder aufladen (Ladezeit beachten: Punkt 1).
4. Um die Leistung des Akkus zu erhalten, den Akku erst dann laden, wenn dieser leer ist.




Ladung:

- Ladekabel mit einem USB Netzteil (nicht inclusive) verbinden (Staus LED blinkt)
- Akku mit Tamiya Stecker am Ladekabel verbinden
- Status LED leuchtet während des Ladevorgangs dauerhaft
- Ladevorgang ist abgeschlossen (Status LED erlischt)

ERSATZTEILE

500800113 Bodyset X-CRAWLEE PRO 3.0 white / Karosserie X-CRAWLEE PRO 3.0 weiß





www.carson-modelsport.com/de/produkte.htm

Gewährleistung: www.carson-modelsport.com/de/service/gewaehrleistung/


HOW TO CONTROL YOUR MODEL

- Raise the tyres off the ground
- Turn the steering wheel to the right and left as far as it will go. The wheels are to follow the steering direction.
- If the wheels operate in the opposite direction, operate the servo Reverse switch (ST in position REV).
- To regulate the driving speed, actuate the throttle/brake
  - backwards (forward driving, accelerating) or
  - forwards (braking, reversing)






A. THROTTLE TRIGGER



B. STEERING WHEEL




CHARGE BATTERY PACK

Charging instructions: Attention!!!!

Important information about your rechargeable 7.2V NiMH Battery pack. (See drawing)

1. The charging time for these 7.2V NiMH Battery pack is max. 3 hours, an overload damage it and shortens the life.
2. Let the charger and the battery during charging never unattended.
3. If the speed / performance of your RC model decreases or even stops, immediately stop operation and charge the battery (Note the charge time: point 1) again.
4. To maintain the performance of the battery, please charge the battery only when it is empty.




Charging:

- Connect the charging cable to a USB power supply (not included) (status LED flashes)
- Connect the battery to the Tamiya plug on the charging cable
- Status LED lights up continuously during the charging process
- Charging process is complete (Status LED goes out)

SPARE PARTS

500800113 Bodyset X-CRAWLEE PRO 3.0 white / Karosserie X-CRAWLEE PRO 3.0 weiß



www.carson-modelsport.com/de/produkte.htm

Warranty declaration: www.carson-modelsport.com/de/service/gewaehrleistung/